



How to Calculate Wardrobe Door Height and Width

1. Establish if your doors are to be hung overlay or inset
2. Measure the height and width of the wardrobe or cabinet in mm. If applying the doors overlay take the measurement from the exterior of the cabinet (do not include the height of the leg, measure the cabinet only) If intending to hang the doors with inset hinges measure the cabinet using the interior width and height.
3. Each door is typically 5mm less than the overall height of the cabinet and 4mm less than overall width.
4. Based on this example the calculation for an overlay application would be:
Exterior Cabinet Height: $2160\text{mm} - 5\text{mm} = 2155\text{mm}$
Exterior Cabinet Width: $1000\text{mm} / 2 \text{ doors} = 500\text{mm} - 4\text{mm} = 496\text{mm}$
5. The door size for this cabinet is $2 \times 2155 \times 496\text{mm}$



To establish if a door is left or right hanging for hinge holes view the door from the front