

## How to Measure for Hinge Holes

Doors can be pre-drilled with hinge holes, please note the following points :

1. The hanging of a door is established by viewing the door from the front NOT the back.
2. Measure from the top and/or bottom of the door to the CENTRE of the hole.
3. The hinge is not just the opening mechanism they support the doors weight and avoid any distortion over time therefore it is important that doors are drilled with sufficient holes.
4. To achieve good stability distances between hinges should be equally spaced out.
5. When planning make sure that there is sufficient depth to mount the hinges and there are no obstructions such as shelves.
6. If using face fix or bi fold hinges the holes provided in manufacture will not be suitable therefore they will need to be drilled on site

